



- **485+,485- :**  
For PTZ Control
- **DIN+,DIN-:**  
Alarm Input
- **DOUT+,DOUT-:**  
Alarm Output
- **Audio L,Audio R:**  
Audio Output
- **MIC In:**  
Audio Input (The Camera was Audio inbuilt, no need to employ Mic In )

• **Video Out:**  
BNC Cable  
Video Output

• **SD Card Record:**  
After the SD card is installed, double press the "SD Card record" button, it will start recording

• **Record LED(Red):** SD Card Record  
• **Server LED(Yellow):** Connection Register Server  
• **Link LED(Green):** Connection Network  
After Self-check, All three LED Lights wil go off

- **BLC:**  
Back Light Compensation
- **AI,EE:**  
AI:Automatic Lens or AIC  
Automatic Light Control  
EE:Electronic Exposure Or  
ELC Electronic Light  
Control
- **AGC:**  
Auto Gain Control
- **AWB:**  
Auto White Balance

• **Level:**Adjust DC Lens

## Back of the CCD IP CAM